

Max. Pipeline Cap: **Rigid** - 163 gal
Flex - 49.6 gal

ALARM & ERROR CODES

TS-LLD

Display Code	Description
00 to 28	Not Flashing (No Alarm or Error) this is a normal display of the number of days since the last monthly line leak test passed.
88	Not Flashing (System OK) the control unit electronics and display is working correctly.

Flashing Display - Alarm and Error Codes

1	Failed Annual (0.1) GPH line leak test
2	Failed Monthly (0.2) GPH line leak test
3	Failed Hourly (3.0) GPH line leak test
29 - 32	Alarm - Over 28 days since the last Monthly line leak test passed. The number that is flashing is the number of days since the last monthly line leak test passed.
80	Annual leak test aborted.
81	Leak Sensing Unit is out of operating range.
82	Leak test aborted -- thermal instability
83	Leak Sensing Unit is not communicating.
84	Pressurized line is out of compliance.
85	Leak Sensing Unit requires cleaning.